

# CARMAGIC, LLC

## Installation of Aluminum trim rings on Porsche 914 Gauges.



**These trim rings can be installed without removing the gauges. No glue or tape is needed**

Instruction:

After removing the new rings from the package, try each ring on the gauge rings for fitment.

At this point they will be loose. Remove the rings and go to next step.



Next: Use a small screw driver to roll the edge of the trim ring slightly so a hook will be created. Do this for all the way around the edge. See picture.

Be careful and just do it very light and test fit. If it's still lose and will not click in, repeat it until the ring clicks in and sits firm.

Repeat this procedure for the rest of the gauges.



Included in this set:

- 1 ring for the tachometer
- 2 rings for Speedo and Gas gauge
- 1 instruction

Option: 3 small rings for center console gauges

Note: The 3 small rings must be glued on with silicon glue, included in the set.



Disclaimer:

The correct installation of the rings is your responsibility. I cannot take any responsibility for any damage to your vehicle or equipment.