


## Installation of new LED BA7s instrument lights.

Disconnect the battery. Remove the steering wheel if it helps to get better access for the removal of the gauges.

Remove the gauges by careful pulling at the ring. If the gauges are tight, it may be necessary to use a screwdriver, or similar tool and careful pry around the edge of the instrument. Try to find the gauge which comes out easy, and reach into the hole and help pushing the other gauges, or follow instructions in the workshop manual.

Remove the bulb holder, and twist the bulb a quarter turn and pull it out.

Once the old bulb is out, insert the new LED in the bulb holder and the bulb holder back into the gauge.



The clock and the Gas/Oil gauge have only one bulb, and the depth for the light bulb on the clock is less as on the other gauges.

Check if the small plastic sleeve is still there, as shown in the picture (Ref. 1). If not, use the included foil tape instead, to close the slots. Next insert the plastic spacer onto the bulb holder before insert the new LED. (Ref. 2). Now insert the new LED into the bulb holder, and the bulb holder into the clock or gauge, make sure the 2 side LED's point left and right and not up and down. (Ref. 3)

Included in this LED set:

8 LED BA7s + 1 spare



Plastic spacer



Foil tape, in case needed.



### Warranty:

The LED lights are warranted for 2 years from the date of purchase. Warranty is void when these 12 volt LED's are used with different voltage. Please email to notify us prior to returning items for warranty exchange. Return shipping costs are the sole responsibility of the customer.

### Disclaimer:

The correct installation of the LED lights is your responsibility, I cannot take any responsibility for any damage to your vehicle or equipment.